

# SOL - series -



MD-6114 T:187/B:95/W:76/H:94



- MD - 6114 . B - A -



- MD - 6114 . B - B -



- MD - 6114 . B - C -




- MD - 6114 . B - D -



- MD - 6114 . B - E -

MD-6116 T:187/B:95/W:76/H:94



- MD - 6116 . B - A -



- MD - 6116 . B - B -



- MD - 6116 . B - C -



- MD - 6116 . B - D -



- MD - 6116 . B - E -

MD-6115 T:187/B:95/W:75/H:92



- MD - 6115 . B - A -



- MD - 6115 . B - B -



- MD - 6115 . B - C -



- MD - 6115 . B - D -



- MD - 6115 . B - F -



腰安定スタンドベース



外部安定

# SOL - series -

MD-6109.B.N B:95/W:77



MD-6117.B.A B:92/W:74



MD-6117.B.B B:92/W:74



MD-6117 は両脚に回転式ジョイントを装備  
1体で各ポーズをとる事が出来ます

## HEAD variation

MD-6115 T:184.5/B:95/W:75/H:92



A type



MD-6115 T:169/B:95/W:75/H:92



DM type



すべてのポーズで Atype DMtype が対応可能です



# MODE CENTER

株式会社 **モードセンター**

本社	〒170-0001 東京都豊島区西巣鴨1-9-6 TEL 03-3918-0411
大阪支店	〒530-0014 大阪市北区鶴野町1-3(安田ビル) TEL 06-6372-7366
名古屋営業所	〒464-0838 名古屋市千種区千種1-15-14 TEL 052-745-7511
仙台営業所	〒980-0802 仙台市青葉区二日町3-5(ハウザービル) TEL 022-225-7661
福岡事務所	〒812-0004 福岡市博多区榎田2-7-14(サンビュー空港7号室) TEL 092-414-6170
札幌事務所	〒003-0834 札幌市白石区北郷四条12-10-10-203 TEL 011-879-5187
商品管理センター	〒353-0002 埼玉県入間郡三芳町大字竹間沢209-1 TEL 049-211-0001
アトリエ	〒354-0013 埼玉県富士見市水谷東3-1-1 TEL 048-487-6787