



Y O G A  
m a n n e q u i n s



**NSP-7808**

T175.0/B84.0/W65.0/H89.0  
wide72.0/FootSize23.0



DW:72785/A:72786/R:72787/N:72788/B:73051



**NSP-7810**

T87.5/B83.0/W64.0/H-  
wide84.0/FootSize-  
DW:72794/A:72795/R:72796/N:72797/B:73052



**NSP-7813**

handtop218.0  
T176.0/B82.0/W63.5/H87.0  
deep80.0/FootSize22.0



DW:72785/A:72786/R:72787/N:72788/B:73051



**NSP-7818-A**

top150.0  
B82.0/W58.0/H88.5  
wide85.0~110.0/deep48.0  
FootSize23.0



B:73110



**NSP-7818-B**

B:73111



**NSP-7818-C**

B:73112



**NSP-7819-A**

top160.0  
B82.0/W58.0/H88.5  
wide65.0/deep48.0  
FootSize23.0



B:73117



**NSP-7819-B**

B:73118



**NSP-7820**

top88.0  
B82.0/W58.0/H88.5  
wide135.0/deep48.0  
FootSize23.0



B:73123



**BOT-112**

T117.0/W59.0/H87.0  
FootSize22.0



10324



**BOT-113**

T117.0/W59.0/H87.0  
FootSize22.0



10325



**BOT-114**

T119.0/W59.0/H87.0  
FootSize22.0



10326



# STAND SYSTEM



■ ガラスベース  
W40.0/D40.0  
56003



■ ガラスベース ストレート  
W40.0/D40.0



■ 底安定スタンド  
W40.0/D40.0  
56006




■ 外部安定スタンド ストレート  
W40.0/D40.0



■ スチールベース  
W48.0/D48.0  
56179



■ スチールベース  
W48.0/D48.0  
56179



■ 底安定スタンド  
W30.0/D30.0  
56180

# BS SYSTEM



■ 腰安定ベース 大  
W40.0/D40.0  
56176

# HEAD VARIATION



type DW



type A



type R



type N



type B

for

NSP-7808  
NSP-7810  
NSP-7813



type B [fix]

for

NSP-7818-A  
NSP-7818-B  
NSP-7818-C  
NSP-7819-A  
NSP-7819-B  
NSP-7820



## MODE CENTER

登録 モードセンター

本社 〒170-0001 東京都豊島区西巣鴨 1-9-6  
TEL 03-3918-0411(代表)

大阪支店 〒530-0014 大阪市北区鶴野町 1-3(安田ビル)  
TEL 06-6372-7366(代表)

名古屋営業所 〒464-0858 名古屋市千種区千種 1-15-14  
TEL 052-745-7511(代表)

仙台営業所 〒980-0802 仙台市青葉区二日町 3-5(ハウザービル)  
TEL 022-225-7661(代表)

札幌事務所 〒003-0834 札幌市白石区北郷四条 12-10-10-203  
TEL 011-879-5187(代表)

福岡事務所 〒812-0004 福岡市博多区榎田 2-7-14(サンヴェー空港7号室)  
TEL 092-414-6170(代表)

商品管理センター 〒354-0043 埼玉県入間郡三芳町竹間沢 209-1  
TEL 049-211-0001(代表)

アトリエ 〒354-0013 埼玉県富士見市水谷東 3-1-1  
TEL 048-471-3522(代表)